

Wheel Alignment

Front Wheel Alignment	Setting	Range
Camber-Cross Camber	0.00-0.00	-0.40~+0.40 / 0.50
Caster-Cross Caster	+2.45 /0.00	+1.45~+3.45 /1.00
Total Toe	+0.20	0.00~+0.40
Rear Wheel Alignment	Setting	Range
Camber	0.00	-0.25~+0.25
Total Toe	+0.20	+0.00~+0.25
Thrust Angle	0.00	-0.30~+0.30